



Print Putty Kit

- Mix Putty A and Putty B thoroughly by kneading together until no swirls are visible. This should take 30-60 seconds.
- Roll mixed putty into ball and place on a clean dry surface. Work quickly as you have approximately 1 min before your putty will start to cure.
- Press finger firmly into the putty ball parallel to the table surface to optimize contact of finger with putty. The indent left by your finger should be half the depth of the original ball. (not too shallow, not too deep). Always use an up and down motion when collecting your print to obtain the maximum detail in your mold.
- Allow your mold to sit and cure for 15 min. During this time label the return packages with the correct name and information to be placed on the print. When the mold is cured place it into corresponding package.
- If doing multiple fingerprints it is recommended to do one at a time.

If you have any questions please feel free to email us at pawpositiveimpressionsinc@gmail.com